

# Calling Genomic Variants from DNaseq data

Oxford Biomedical Data Science Training Programme

# Genomic DNA Sequencing

- Whole genome sequencing
- Exome sequencing (2% of genome)
- Targeted panel (~10-100 genes)
- Variant types
  - Single nucleotide variants
  - Small insertions and deletion (indels)
  - Copy number variations
  - Structural variations

# Germline vs Somatic Variants


## Germline

- Rare disease
- *De novo* mutations
- Trio or family
- Assume diploid


## Somatic

- Cancer
- Tumour vs germline
- Tumour purity
- Tumour heterogeneity
- Cannot assume diploid

# SNV / Indel Calling Workflow




# Step 1 - QC of Raw Sequencing Data




# Read Quality Control

- FastQC
- Traffic light overview
- Graphical summaries
- HTML report




## Step 2 - Mapping Reads to a Reference Genome



# Mapping Reads

- Find the position(s) in the reference genome where each short read sequence aligns with the fewest mismatches
- Must be fast (millions of short reads)
- Must allow small differences (sequencing errors or polymorphisms)
- String matching problem






# Short Read Mapping Tools

- General purpose alignment tools: BLAST, BLAT
- First short read specific tools:
  - Eland, MAQ – use hash tables
- Second generation tools:
  - Bowtie, BWA – Burrows-Wheeler Transform
- Third generation tools:
  - SOAP3 – uses GPU processing
- Trade off between sensitivity, specificity and processing time
- For DNaseq we want accurate SNP/indel detection so specificity is key


# Burrows-Wheeler Aligner

- Recommended by the Broad Institute best practice guidelines
- Aligns short sequences (< 400nt) against long reference genome
- Fast (if not too many errors)
- Gapped alignment (enables short indel calling)
- Soft clipping (ends of reads do not have to align)
- Takes FASTQ as input
  - Requires Sanger quality score format
- Produces SAM as output
- Default parameters optimised for mammalian DNA sequencing
- New algorithm BWA-MEM now recommended for read length > 70bp

# Step 3 - QC of Mapped Reads



# Picard Tools

- SAM/BAM/CRAM & VCF processing
  - Overlapping functionality with Samtools/Pysam
  - Written in Java
  - Broad Institute
  - Many BAM Quality control tools
    - CollectAlignmentSummaryMetrics
    - CollectBaseDistributionByCycle
    - CollectGcBiasMetrics
    - CollectHsMetrics
- 
- CollectMultipleMetrics**

# Target Coverage Metrics

- ON\_BAIT\_BASES: The number of PF aligned bases that mapped to a baited region of the genome.
- NEAR\_BAIT\_BASES: The number of PF aligned bases that mapped to within a fixed interval of a baited region, but not on a baited region.
- OFF\_BAIT\_BASES: The number of PF aligned bases that mapped to neither on or near a bait.
- ON\_TARGET\_BASES: The number of PF aligned bases that mapped to a targeted region of the genome.
- MEAN\_BAIT\_COVERAGE: The mean coverage of all baits in the experiment.
- MEAN\_TARGET\_COVERAGE: The mean coverage of targets that received at least coverage depth = 2 at one base.
- FOLD\_ENRICHMENT: The fold by which the baited region has been amplified above genomic background.
- ZERO\_CVG\_TARGETS\_PCT: The number of targets that did not reach coverage=2 over any base.
- PCT\_TARGET\_BASES\_20X: The percentage of ALL target bases achieving 20X or greater coverage.

BAIT_SET	rgPicardHsMet
GENOME_SIZE	3101804739
BAIT_TERRITORY	51680059
TARGET_TERRITORY	51680059
BAIT_DESIGN_EFFICIENCY	1
TOTAL_READS	1070677
PF_READS	1070677
PF_UNIQUE_READS	1070677
PCT_PF_READS	1
PCT_PF_UQ_READS	1
PF_UQ_READS_ALIGNED	1006099
PCT_PF_UQ_READS_ALIGNED	0.939685
PF_UQ_BASES_ALIGNED	100941269
ON_BAIT_BASES	60373413
NEAR_BAIT_BASES	23200732
OFF_BAIT_BASES	17367124
ON_TARGET_BASES	60373413
PCT_SELECTED_BASES	0.827948
PCT_OFF_BAIT	0.172052
ON_BAIT_VS_SELECTED	0.722393
MEAN_BAIT_COVERAGE	1.168215
MEAN_TARGET_COVERAGE	113.898567
PCT_USABLE_BASES_ON_BAIT	0.558298
PCT_USABLE_BASES_ON_TARGET	0.558298
FOLD_ENRICHMENT	35.897849
ZERO_CVG_TARGETS_PCT	0.32985
FOLD_80_BASE_PENALTY	3.451472
PCT_TARGET_BASES_20X	0.010046


Expect > 60% selected bases

Expect > 80% bases covered at 20x

Expect enrichment > 30x

# Removing Duplicate Reads

- Remove read pairs with identical mapping coordinates
  - Assumed to be PCR duplicates
  - Unlikely to happen by chance in WGS
- Sets duplicate flag in BAM file
- Can also remove duplicates from file




# Output from Picard MarkDuplicates

- READ\_PAIR\_DUPLICATES:
  - The number of read pairs that were marked as duplicates.
- PERCENT\_DUPLICATION:
  - The percentage of mapped sequence that is marked as duplicate.
- ESTIMATED\_LIBRARY\_SIZE:
  - The estimated number of unique DNA molecules in the library based on paired end duplication.

```
## METRICS CLASS net.sf.picard.sam.DuplicationMetrics
## HISTOGRAM java.lang.Double
LIBRARY UNPAIRED_READS_EXAMINED READ_PAIRS_EXAMINED UNMAPPED_READS
UNPAIRED_READ_DUPLICATES READ_PAIR_DUPLICATES READ_PAIR_OPTICAL_DUPLICATES
PERCENT_DUPLICATION ESTIMATED_LIBRARY_SIZE
AGILENT50MM 1095 633960 1098 375 99531 0 0.157159 1801628
```

# Step 4 - Variant Calling





# Genome Analysis Toolkit

[Best Practices](#)[User Guide](#)[Blog](#)[Forum](#)[Events](#)[Download](#)

## Genome Analysis Toolkit

Variant Discovery in High-Throughput Sequencing Data



Developed in the Data Sciences Platform at the [Broad Institute](#), the toolkit offers a wide variety of tools with a primary focus on variant discovery and genotyping. Its powerful processing engine and high-performance computing features make it capable of taking on projects of any size.

[Learn More](#)

### Best Practices

Pipelines optimized for accuracy and performance



### Blog

Announcements and progress updates



### User Guide

Detailed documentation, tutorials and resources



### Forum

Ask the team for help and report issues



### Events calendar

Webinars, workshops, conferences



Run GATK on Cloud




Download GATK 4.0



© Broad Institute 2018


# GATK Best Practices Workflow




# Base Quality Score Recalibration

- **Improves accuracy of base quality scores to reduce false positive variant calls**
- Analyse the variation among several features of a base:
  - Reported quality score
  - The position within the read
  - The preceding and current nucleotide (sequencing chemistry effect)
- These covariates are used to recalibrate the quality scores of all reads in a BAM file
- For example, a pre-calibration file could contain only reported Q25 bases
- These bases actually mismatch the reference at a 1 in 100 rate, so are actually Q20 empirically
- Base mismatches with the reference occur at the end of the reads more frequently than at the beginning
- Mismatches are strongly associated with sequencing context, in that the dinucleotide AC is often much lower quality than TG
- The recalibration tool corrects average Q score (shifting from Q25 to Q20)
- Also reduces quality of end of read AC bases compared to TG bases at the start of the read


Before




After



RMSE = 2.514



RMSE = 0.36



Reduced error  
per machine  
cycle

# GATK HaplotypeCaller

- Call SNVs & indels by performing a local de-novo assembly
- Offers improved indel detection & phases haplotypes (vs UnifiedGenoypers)
- De-novo assembly method
  - Determine if a region has the potential to be variable
  - Construct a de Bruijn graph assembly of the region
  - The paths in the graph are potential haplotypes to be evaluated
  - Calculate haplotype likelihoods given the data
  - Determine if there are any variants on the most likely haplotypes
  - Compute the allele frequency distribution to determine most likely allele count
- Performed on each sample
- Produces a Genome VCF (.gvcf) file
- GVCFs can be combined using CombineGVCFs

# Joint Genotyping

- Gain power by calling variants on multiple samples
- Computationally inexpensive
- Works on combined GVCFs
- GenotypeGVCFs

# Variant Quality Score Recalibration

- Variant calling is very sensitive
- Machine learning to identify variants that are likely to be real
  - Trains a model based on annotations of known variants
  - Applies the model to the entire dataset
  - Needs large, high quality set of known variants

# VCF File Format

Headers	##fileformat=VCFv4.0									
	##fileDate=20090805									
Entries	##source=myImputationProgramV3.1									
	##reference=1000GenomesPilot-NCBI36									
Headers	##phasing=partial									
	##INFO=<ID=NS,Number=1,Type=Integer,Description="Number of Samples With Data">									
Entries	##INFO=<ID=DP,Number=1,Type=Integer,Description="Total Depth">									
	##INFO=<ID=AF,Number=.,Type=Float,Description="Allele Frequency">									
Headers	##INFO=<ID=AA,Number=1,Type=String,Description="Ancestral Allele">									
	##INFO=<ID=DB,Number=0,Type=Flag,Description="dbSNP membership, build 129">									
Entries	##INFO=<ID=H2,Number=0,Type=Flag,Description="HapMap2 membership">									
	##FILTER=<ID=q10,Description="Quality below 10">									
Headers	##FILTER=<ID=s50,Description="Less than 50% of samples have data">									
	##FORMAT=<ID=GT,Number=1,Type=String,Description="Genotype">									
Entries	##FORMAT=<ID=GQ,Number=1,Type=Integer,Description="Genotype Quality">									
	##FORMAT=<ID=DP,Number=1,Type=Integer,Description="Read Depth">									
Headers	##FORMAT=<ID=HQ,Number=2,Type=Integer,Description="Haplotype Quality">									
	#CHROM	POS	ID	REF	ALT	QUAL	FILTER	INFO	FORMAT	NA000001
Entries	20	14370	rs6054257	G	A	29	PASS	NS=3;DP=14;AF=0.5;DB;H2	GT:GQ:DP:HQ	0/0:48:1
	20	17330	.	T	A	3	q10	NS=3;DP=11;AF=0.017	GT:GQ:DP:HQ	0/0:49:3
Headers	20	1110696	rs6040355	A	G,T	67	PASS	NS=2;DP=10;AF=0.333,0.667;AA=T;DB	GT:GQ:DP:HQ	1/2:21:6
	20	1230237	.	T	.	47	PASS	NS=3;DP=13;AA=T	GT:GQ:DP:HQ	0/0:54:7
Entries	20	1234567	microsat1	GTCT	G,GTACT	50	PASS	NS=3;DP=9;AA=G	GT:GQ:DP	0/1:35:4
Location		Alleles		Info				Format		



# Alternative Variant Callers

## Joint Genotyping

- Samtools
- SomaticSniper
- FaSD-somatic
- JointSNVMix2
- Virmid
- SNVSniffer
- CaVEMan

## Heuristic


- VarScan2
- SOAPsnv
- VarDict
- qSNP
- RADIA
- Shimmer

## Joint Allele Freq

- Mutect2
- Strelka2
- LoFreq
- EBCall
- deepSNV
- LoLoPicker
- MuSE

Machine learning / ensemble methods: MutationSeq, SomaticSeq, SNooPer, BAYSIC

## Step 5: Variant Annotation & Filtering



# Variant Annotation

- Determining the potential biological action of SNVs and small indels
- Known variants
  - dbSNP identifier (rs number)
  - 1000 genomes allele frequency (rare / common)
- Variant location
  - Intron, UTR, CDS, splice site, promoter etc
- Variant effect
  - Non-synonymous coding / missense
  - Predicted effect (SIFT, Polyphen2, Provean)
  - Nonsense (premature stop codon)
  - Frameshift (indels)
- Variant evolutionary conservation
  - GERP, PhastCons
- Regulatory effects
  - Transcription factor binding sites
  - microRNAs
  - CpG islands
- Phenotype and disease association

# Variant Annotation Tools



<http://www.ensembl.org/info/docs/tools/vep/index.html>



<http://www.mutationtaster.org/StartQueryEngine.html>

## wANNOVAR

ANNOVAR is a rapid, efficient tool to annotate functional consequences of genetic variation from high-throughput sequencing data. wANNOVAR provides easy and intuitive web-based access to the most popular functionalities of the ANNOVAR software

Get Started

About

Contact

<http://wannovar.usc.edu/index.php>



Annotation, Visualization, and Impact Analysis

[http://avia.abcc.ncifcrf.gov/apps/site/sub\\_analysis/?id=3](http://avia.abcc.ncifcrf.gov/apps/site/sub_analysis/?id=3)

## SNPnexus

<http://www.snp-nexus.org/>

# VCF Filtering Tools

- Filtering of VCF files can be done using several tools
  1. SnpSift filter
  2. VCFfilter (part of the VCFlib toolkit)
  3. GATK Select Variants
- Can filter on any logical combination of fields
- Syntax varies between tools

# VCF Filtering Schemes for Different Genetic Models

- De novo variants
  - Homozygous reference in unaffected parents and heterozygous in proband
- Recessive variants
  - Heterozygous in unaffected parents and homozygous non-reference in affected proband
  - Can also be compound heterozygous in proband (two different mutations in the same gene)
- Dominant variants
  - Heterozygous in affected individuals but homozygous reference in unaffected

# Related workflows

- RNAseq variant calling
- UMI-based variant calling
- Structural variants
- Copy number variants